ARCTIC VERGE

# HOW TO START THE FIREPLACE

A quick guide for your cozy stay at Lake Munajarvi

## 1 OPEN THE CHIMNEY DAMPER FIRST

The metal knob on the chimney pipe controls the smoke outlet.



**OPEN - PULL OUT**



**CLOSED - PUSH IN**

**Keep the damper OPEN while the fire is burning or embers are still hot.**

## 2 PREPARE THE FIRE

We have placed a few small pieces of starter wood for you.
Put them inside the fireplace with a little birch bark.

## 3 LIGHT THE BIRCH BARK

Light the birch bark - it is your natural fire starter.
Keep the fireplace door closed during normal burning.

## 4 ADD FIREWOOD

When the small wood is burning properly, add up to TWO logs.
Add more only when needed; never overload the stove.

## MAXIMUM 2 PIECES OF FIREWOOD AT A TIME

Never add more than two logs at once.

### IMPORTANT SAFETY

Use only dry firewood and birch bark. Do not use lighter fluid or burn rubbish.
Never close the chimney damper while flames or hot embers remain.
Keep children away from hot surfaces. Never leave an active fire unattended.
If smoke enters the room or an alarm sounds: go outside and call 112.